



Power Supply - Wall Plug (No Doorbell Chime)



***This setup requires a 10 Ohm / 10 Watt resistor**

This setup is not compatible with a doorbell chime. Do not use a resistor if you are adding a doorbell chime.

Power Supply - Adapter (No Doorbell Chime)



***This setup requires a 10 Ohm / 10 Watt resistor**

This setup is not compatible with a doorbell chime. Do not use a resistor if you are adding a doorbell chime.